

## **GROUP 26**

# **FRONT AXLE**

### **GENERAL**

#### **OUTLINE OF CHANGES**

- The disassembly and reassembly procedures for the axle hub have been added to correspond to the addition of the diesel-powered vehicle. In addition, the procedures are the same as for 1600 models.  
Applicable models: 1900D